


PREPARATION BEFORE OPERATION (SETTING CURRENT TIME)

- 1** Press the
CLOCK
button



- 2** Press the TIME
button to set
the time





- 3** Press the DAY
button to set
the day

- 4** Press CLOCK
again

3D i-SEE SENSOR™



SENSOR: The sensor detects the room temperature




ABSENCE DETECTION: When no one is in the room, the unit automatically switches to Energy-saving mode.



INDIRECT/DIRECT: Press  to activate INDIRECT/DIRECT mode. This mode is only available when the i-see control mode is effective.



The 3D i-see Sensor detects the location of occupants in the room. Direct mode aims airflow toward individuals in the space while Indirect mode diverts air away from room occupants.




NOTE: In the case of systems with multiple units (multi-systems), it is not possible to set different operation modes for each unit. In some cases, it may not be possible to use certain functions.



SIMPLE REMOTE CONTROLLER USER GUIDE

MSH-FH SERIES



© 2019 Mitsubishi Electric Trane HVAC US LLC. All rights reserved.

Mitsubishi Electric and the three-diamond logo are trademarks of Mitsubishi Electric Corporation.

All other product names mentioned herein are trademarks or registered trademarks of their respective owners. Use of the AHRI Certified™ mark indicates a manufacturer's participation in the certification program. For verification of certification for individual products, go to www.ahridirectory.org.





Specifications shown in this brochure are subject to change without notice. See complete warranty for terms, conditions and limitations. A copy is available from Mitsubishi Electric.



SKU: ME-FH-CNTRL-TRIFOLD | 08-2019 | Printed in the USA

© 2019 Mitsubishi Electric Trane HVAC US LLC. All rights reserved.

SELECTING OPERATION MODES

- 1 Press  to start operation
- 2 Press  to select operation mode. Each press changes mode in the following order

- 3 Press  to set the temperature. Each press raises or lowers the temperature by 1°

CONVENIENT ONE-TOUCH FUNCTIONS

Press these buttons to toggle these functions on/off.

ECONO COOL
A swing pattern is used for airflow to create an enhanced cooling sensation. This allows the temperature to be set 2° higher without any loss of comfort.

POWERFUL
Air conditioner operates at maximum capacity for 15 minutes.




SMART SET
Assign your favorite temperature set point to the Smart Set button. Then recall the setting on demand with the simple push of the Smart Set button. Pressing it again will return the temperature to the previous set point.

In normal heating mode, the lowest possible temperature setting is 61° F, but using Smart Set, this value can be set as low as 50° F.

WHAT IS NATURAL FLOW?

NATURAL FLOW
As time passes, airflow will become more like natural wind. The continuous gentle breeze provides enhanced comfort for occupants.
Press this button to toggle the function on/off.

3D i-SEE SENSOR™ OPERATION


- 1 Gently press  using a thin instrument during COOL, DRY, HEAT and AUTO mode to activate i-see control mode.
 - This symbol appears on the operation display. The default setting is "active"
- 2 Press  again to activate ABSENCE DETECTION.
 - This symbol appears on the operation display
- 3 Press  again to release i-see control mode.


    
(AUTO) (COOL) (DRY) (HEAT) (FAN)





* Turn brochure over for more information on 3D i-see Sensor operation.


FAN SPEED & AIRFLOW DIRECTION ADJUSTMENT


FAN
Press  to select fan speed. Each press changes fan speed in the following order:







WIDE VANE
Press  to select horizontal airflow direction. Each press changes airflow direction in the following order:








L-VANE-R
Press  to select airflow direction. Each press changes airflow direction in the following order:








TIMER OPERATION


ON/OFF TIMER
Press  or  during operation to set the timer.
 (ON timer) : The unit turns ON at the set time.
 (OFF timer) : The unit turns OFF at the set time.



Press  (Increase) and  (Decrease) to set the time of timer.
Press  or  again to cancel timer.



WEEKLY TIMER
1 Press  to enter the weekly timer setting mode.

2 Press  and  to select setting day and number.

3 Press , , and  to set ON/OFF, time, and temperature.

4 Press  to complete and transmit the weekly timer setting.

5 Press  to turn the weekly timer ON. ( lights.)

* Press  again to turn the weekly timer OFF. ( goes out.)